

# SAN - Dell Equallogic CLI Notes

```
group1> member select MEMBERNAME eth sel 1 NEWIPADDRESS NETMASK  
group1> grpparams group-ipaddress IPADDRESS
```

Then go back and fix the other network.

```
group1> member select MEMBERNAME eth sel 0 NEWIPADDRESS NETMASK
```

Then set the new default gateway

```
group1> member select MEMBERNAME def-gateway IPADDRESS
```

Supported Update Paths

<https://eqsupport.dell.com/support/download.aspx?id=6442456361>

Reset

```
Press Ctrl/p  
setenv RESETPASSWORD 1  
reload  
account select grpadmin passwd  
group1> reset
```

Change VLAN

```
grpparams dcb def-vlan-id 609
```

Downgrade FW

**THIS WILL WIPE THE SAN**

Transfer FW, login as "root / grpadmin"

```
update.sh -override-downgrade
```

Revision #4

Created 25 July 2018 01:22:37 by Dave

Updated 17 July 2019 17:26:40 by Dave